

AVKOTE Aqua Cotta

Guide lines for the application of AVKOTE Aqua Cotta.

1. MATERIALS

COATING

Top Coat

AVKOTE Aqua Cotta

2. APPLICATION

Stage 1

Remove all dust and loose flake from the surface with a brush. Repeat application should only be made over fully hardened coatings. Before treating a large area check the suitability of the surface by making a test on a small area

Stage 2

Spray a copious coating onto the surface, this must be visibly wet for a short period. When applying onto pots firstly apply a coating on the inside then the outside. The application of "too much" material does not affect the effectiveness of the product. Do not use at temperature below 10°C.

Stage 3

Pots - plants can be planted 24 hours after application. Flooring - do not walk on for 24 hours, you can protect but do not cover, the product must evaporate to dry properly.

3. RESTORATION

No special care is required. If the surface has been abraded or the pearl effect is no longer effective, a repeat treatment can be applied at any time. These products are not suitable for glass, car windows, strong alkali materials such as fresh concrete, delicate plastic such as Plexiglas and freshly painted surfaces.

This information is a standard recommendation. The application should be adapted to local standards. No liability or claim can be made from this