



### Quick Reference Guide

<b>Solvent Products</b>		
<b>Code</b>	<b>Paint Products</b>	<b>Description / Substrates</b>
1000LE	AVKOTE LE	For application on to PVCu, GRP, MDF, Powder Coated Ali and Acrylic. With the use of 2250 primer it can also be applied to Ali and Steel. With the use of SFP it can be applied to MDF, Chipboard, Ply and other wood based products (ideal for kitchens and bathrooms)
1014	AVKOTE GP	For application onto Glass. Some of the finishes are solid colours, frosted, translucent, metallic, sparkles and crackle effects
1009LE/FL	AVKOTE FL (Fineline)	As LE but a chalky finish. Ideal for kitchens. Internal use only
1000LEM	AVKOTE LE – Matt	A matt finish for application onto PVCu and GRP. Being a matt finish, this may reduce longevity over a period of time, therefore we cannot guarantee how long this product/finish will last when applied externally.
1012	AVKOTE PC	For application on to Plastisol sheeting that requires refurbishment on site. Slower drying time.
1018	AVKOTE EG	For application on to PVCu. With the use of Primer 2250 it can also be used on metal. AVKOTE EG emulates a powder coat finish.
1016	AVKOTE FE	For application onto furniture & wood. 3910 primer/1090 filler or AVKOTE SFP will be required
1015	AVKOTE KF	For application onto furniture & wood. 3910 primer/1090 filler or AVKOTE SFP required first. Very hard finish. It can also be applied onto GRP & PVCu for extra hard wearing surfaces
1019	AVKOTE WE	For application onto wood. Teak, Mahogany and Wenge. AVKOTE 242 Marine needs to be applied first
1017	AVKOTE ME	For application onto Metal. 2250 Primer required
1001LE/IR – 1005LE/IR	AVKOTE HR	For application onto PVCu & GRP with a special IR reflecting component to minimise UV build up
2000SP	AVKOTE BSP	For application onto primed iron, steel, aluminium and metal. 2250 primer will be required. High gloss finish
1010RLE	AVKOTE RLE	Roller/brush version of AVKOTE LE. ONLY for small areas
1011SLE	AVKOTE SLE	As LE but a Single pack version. ONLY to be used on small areas
1014SSP	AVKOTE Solid Sparkle	Clear coat lacquer containing a coloured sparkle flex for glass. Interior use only
1014SCSP	AVKOTE Scattered Sparkle	Clear coat lacquer containing a coloured sparkle flex for glass. Interior use only
1014/ Crackle	AVKOTE Crackle Glaze	For application onto glass. To be applied after the 1480C Lacquer. Interior use only



4417	AVKO Mirror	For application onto glass, acrylic and PMMA sheets. Interior use only
<b>Code</b>	<b>Cleaners</b>	<b>Description / Substrates</b>
4101	Cleaner 153 B	Pre cleaner. Tints the surface blue and must then be thoroughly cleaned off with 154 cleaner
4100	Cleaner 154	Specially developed cleaner for PVCu & Plastisol sheeting as well as to clean grime on PVCu.
4103	Glass Cleaner	Specially developed cleaner for glass
4104	Isopropanol Cleaner	Not as harsh as the 154 cleaner. For PVCu foam board
4102	U Cleaner	Cleaner for metal
6066	Panel Wipe	Degreaser/silicone remover
<b>Code</b>	<b>Adhesion Promoters</b>	<b>Description / Substrates</b>
4202	PP 502 – Polypropylene & Polyethylene Primer	For application onto Polypropylene & Polyethylene plastics. Spray on and then apply AVKOTE LE
<b>Code</b>	<b>Additives</b>	<b>Description / Substrates</b>
4400	Contrasil	To be added to paint in the AVKOTE LE Range if you have detected silicone on the substrate
<b>Code</b>	<b>Hardeners</b>	<b>Description / Substrates</b>
4300	Hardener 279	Hardener for AVKOTE LE, GP, FL, PC, DP, Universal, FE,KF,ME, WE,HR, PC,EG, RLE, BSP & Lacquers 1480c,1483, 1485, 1484, 1495, Glass Lacquer, DP Lacquer, Soft Touch Lacquer, SFP Primer, 1200 series and SM varnish
4304	AVKOTE 243 Hardener	For use with AVKOTE 242 Furniture/242 Marine
4302	AVKOTE 1091 Hardener	For use with AVKOTE 1090 Filler Primer
4301	AVKOTE 2243 Hardener	For use with AVKOTE 2250 Primer
4309	AVKOTE 9145 Hardener	For Universal ST
4311	AVKOTE H3910 Hardener	For use with AVKOTE 3910 Primer
4315	AVKOTE 1049 Hardener	For use with AVKOTE Mirror paint
<b>Code</b>	<b>Primers</b>	<b>Description/Substrates</b>
4201	Primer / Filler 1090	For use on wood based products - any AVKO paint can be applied on top. Interior only
4205	AVKOTE Primer 2250	For use on Ali, Iron, Steel, Concrete, Powder coating and GRP substrates - any AVKO paint can be applied on top. Available in white
4252	Primer 3910	A 2K sealer primer for use on corners and cut edges. Ideal for use with substrates for fitted kitchens, bedroom furniture, many shop fitting, plastic & exhibition, MDF and display uses. Interior only
4203	AVKOTE SFP Sealer/Filler/Primer	A 2k sealer, filler & primer. Just 2 coats required. For MDF and other wood based products. Ideal for kitchens and bathrooms. Interior only
<b>Code</b>	<b>Lacquers</b>	<b>Description/Substrates</b>
4503	Clear Lacquer 1484	For use in catalytic dryers. When used with a catalytic dryer you will get a satin finish. If you use without the catalytic dryer and let it air dry, you will get a matt finish
4500	Clear Lacquer 1485	Satin lacquer



4501	Clear Lacquer 1483	Medium gloss lacquer
4502	High Gloss Lacquer 1495	High gloss lacquer
4505	Glass Lacquer	For glass. Internal use only
4403	Soft Touch Lacquer	Clear coat top coat for PVCu and furniture. Internal use only. Low wear areas. Velvet soft feel
4507	Clear Lacquer 1480C	For coating of glass prior to the application of AVKOTE GP Crackle Glaze. Interior use only
<b>Code</b>	<b>Thinners</b>	<b>Description/Substrates</b>
4001	Thinner 95	For use with AVKOTE LE (mixing scheme only)
4002	Thinners 550 slow	For use with AVKOTE PC (if thinning the product yourself)
4004	Thinners 3000	For use with thinning 2250 primer
4000	Gun Wash	Standard thinners for cleaning of equipment after use
	<b>Varnishes</b>	<b>Description/Substrates</b>
4207	AVKOTE 242 Furniture	Clear. Filler/primer/top coat for interior wood. Glossy
4206	AVKOTE 242 Marine	Clear. Primer & top coat for exterior wood & can be used in the marine environment. Glossy
4610-4616	AVKOTE 1200 Series	Clear. Base/top coat for interior furniture, especially chairs, benches and tables. Available in different gloss levels
4600-4604	AVKOTE SM	Clear. For interior wood/furniture. Can be used as a top coat over painted surface or on its own as a finish. Available in different gloss levels

### High Solids Universal Range

Code	Paint Product	Description / Substrates
4132DS	AVKOTE Universal Satin/Medium Gloss	For one coat application with no primer onto steel, aluminium, GRP, PVCu, MDF, ABS, rough and foil chipboard, hot dip galvanised surfaces, plastics and non-ferrous metals.
4133DS	AVKOTE Universal High Gloss	For one coat application with no primer onto steel, aluminium, GRP, PVCu, MDF, ABS, rough and foil chipboard, hot dip galvanised surfaces, plastics and non-ferrous metals.
3024	AVKOTE Universal ST	For coating switch gear, machinery, MDF, foiled and raw chip board. Primer required for aluminium and MDF. Interior use only
1013	AVKOTE DP	Top coat for PVCu windows & doors
<b>Code</b>	<b>Thinners</b>	<b>Description / Substrates</b>
4005	Thinners 13000	For use if thinning AVKOTE Universal Range & DP (fast drying)
4001	Thinners 95	For use if thinning AVKOTE Universal Range & DP (slow drying)



<b><u>Water Based Products</u></b>		
<b>Code</b>	<b>Paint Product</b>	<b>Description / Substrates</b>
2620	AQUAKOTE HU	2k high quality topcoat for PVCu and foil faced chipboard. Satin finish
2621	AQUAKOTE WGP	Topcoat for glass. Water –thinnable quick drying 2k product
<b>Code</b>	<b>Hardeners</b>	<b>Description / Substrates</b>
4312	AQUAKOTE H7515	For use with AQUAKOTE HU
4313	AQUAKOTE 5070	For use with AQUAKOTE WGP
4309	AQUAKOTE W3959	For use with AQUAKOTE MT
	<b>Stains</b>	<b>Description / Substrates</b>
4700	KS Stain Black 225	For application over AVKOTE LE or on its own onto textured wood grain PVCu/GRP to achieve a realistic looking wood grain finish to the substrate. A clear coat or varnish must be used to seal it in .Mutton cloth or sponge can be used
4701	KS Stain Brown 220	For application over AVKOTE LE or on its own onto textured wood grain PVCu/GRP to achieve a realistic looking wood grain finish to the substrate. One of our clear coats/ varnishes must be used to seal it in. Mutton cloth or sponge can be used
4702	Irish Stain	For application over AVKOTE LE or on its own onto textured wood grain PVCu/GRP to achieve a realistic looking wood grain finish to the substrate. One of our clear coats/ varnishes must be used to seal it in. Mutton cloth or sponge can be used
	<b>Varnishes</b>	<b>Description / Substrate</b>
4620-4623	AQUAKOTE MT	Clear. Undercoat and/or top coat for interior wood surfaces in commercial kitchens/restaurants. With the use of hardener 3959 this coating has high scratch resistance. Can be brushed/roller applied. Available in different gloss levels
4624	AQUAKOTE MT-TE	Clear satin finish. For interior stairs (floor coating). Satin matt. Can be brushed/roller applied